

TOAMS - Electrical Signal Head Configuration Attribute

Head Configuration Picklist															Program- mable
1-GA						X									
1-P	-PEDESTRIAN (SINGLE MODULE)-														
1-R	X														
1-Y		X													
2-P	-PEDESTRIAN (DUAL MODULE)-														
3-PHB	XX	X													
3-A				X	X	X									
3-H	X	X	X												
3-HA	X	X				X									
3-HL2	X							X		X					
3-HL3							X	X		X					
3-HP	X	X	X												X
3-V	X	X	X												
3-VA	X	X				X									
3-VAP	X	X				X									X
3-VL FYA							X	X	X						
3-VL1	X	X								X					
3-VL2	X							X		X					
3-VL3							X	X		X					
3-VLP3							X	X		X					X
3-VP	X	X	X												
3-VR	X	X												X	
3-VR2	X											X		X	
3-VR3										X	X			X	
4-HL	X	X	X							X					
4-VL	X	X	X							X					
4-VL FYA							X	X	X	X					
4-VR	X	X	X											X	
4-VR FYA										X	X	X	X		
5-HL	X	X	X					X		X					
5-HR	X	X	X									X		X	
5-VL	X	X	X					X		X					
5-VR	X	X	X									X		X	

LEGEND	
Head Graphic	R = Red Y = Yellow G = Green FY = Flashing Yellow
Head Name	Start Number = number of indications/modules P = Programmable (unless noted as Pedestrian) PHB = Pedestrian Hybrid Beacon H = Horizontal V = Vertical A = Ahead arrow(s) L = Left arrow(s) R = Right arrow(s) FYA = Flashing yellow arrow End Number = if more than one, number of arrow indications (Note - No A, L, or R indicates all circular indications)