



Table of Contents

1.3 Types of Bridge Inspections and Assessments	4
1.3.1 Introduction.....	4
1.3.2 Initial Inspection.....	4
1.3.2.1 Purpose	4
1.3.2.2 Precision	7
1.3.2.3 Inspection Interval	8
1.3.3 Routine Inspection.....	9
1.3.3.1 Purpose	9
1.3.3.2 Precision.....	9
1.3.3.3 Routine Inspection Interval.....	10
1.3.4 In-Depth Inspection	12
1.3.4.1 Purpose	12
1.3.4.2 Precision.....	13
1.3.4.3 In-Depth Inspection Interval	13
1.3.5 Nonredundant Steel Tension Member (Fracture Critical) Inspection	14
1.3.5.1 Purpose	14
1.3.5.2 Precision	16
1.3.5.3 Nonredundent Steel Tension Member Inspection Interval	16
1.3.5.4 Specific Inspection Procedures	18
1.3.5.5 NSTM Supplemental Inspection Form.....	20
1.3.5.6 Highway Structures Inventory System (HSIS)	20
1.3.5.7 Redundant Members.....	20
1.3.6 Underwater Profile Activity.....	23
1.3.6.1 Purpose	23
1.3.6.2 Precision.....	26
1.3.6.3 Inspection Interval	27
1.3.6.4 Equipment.....	28
1.3.7 Scour Monitoring Activity (Scour Monitoring Inspection per SNBI)	28
1.3.8 Underwater Dive Inspection.....	29
1.3.8.1 Purpose	29
1.3.8.2 Precision.....	30
1.3.8.3 Underwater Dive Inspection Interval.....	33
1.3.8.4 Methods of Underwater Dive Inspection.....	35



1.3.8.5 Inspection Equipment and Tools	36
1.3.8.6 Underwater Dive Inspection Procedures	39
1.3.9 Underwater Probing.....	41
1.3.9.1 Inspection Equipment and Tools	42
1.3.9.2 Underwater Probing Activity Interval	42
1.3.10 Special Inspection	42
1.3.10.1 Purpose	42
1.3.10.2 Special Inspection – Isolated Activity	43
1.3.10.3 Special Inspection for Completed Repairs or Overburden Change.....	43
1.3.10.4 Special Inspection Procedures	44
1.3.10.5 Special Inspection Interval	44
1.3.11 Damage Inspection.....	44
1.3.11.1 Purpose	44
1.3.11.2 Precision	45
1.3.11.3 Damage Inspection Interval.....	46
1.3.12 Service Inspection	46
1.3.12.1 Purpose	46
1.3.12.2 Service Inspection Interval	46
1.3.13 Complex Feature Inspection	46
1.3.13.1 Purpose	46
1.3.13.2 Bridge Inspection Procedures	47
1.3.13.3 Complex Feature Inspection Interval.....	48
1.3.14 Closed Bridge - Routine Inspection.....	48
1.3.14.1 Purpose	48
1.3.14.2 Interval	49
1.3.15 Closed Bridge Criteria.....	49
1.3.15.1 Introduction	49
1.3.15.2 Closure Criteria	50
1.3.15.3 Bridge Closure Actions.....	50
1.3.16 Load Posted Verification Activity.....	51
1.3.16.1 Purpose	51
1.3.16.2 Precision	52
1.3.16.3 Interval	52
1.3.17 Deck Evaluation Activity	53



1.3.17.1 Purpose	53
1.3.17.2 Precision	53
1.3.17.3 Interval	53
1.3.18 Scour Plan of Action Activity	54
1.3.18.1 Purpose	54
1.3.18.2 Precision	54
1.3.18.3 Interval	54
1.3.19 Vertical Clearance Measured Activity	54
1.3.19.1 Purpose	54
1.3.19.2 Precision	55
1.3.19.3 Interval	55
1.3.20 Critical Findings Activity	55
1.3.20.1 Purpose	55
1.3.20.2 Precision	56
1.3.20.3 Interval	56
1.3.21 Structural Review Activity	56
1.3.21.1 Purpose	56
1.3.21.2 Precision	57



1.3 TYPES OF BRIDGE INSPECTIONS AND ASSESSMENTS

1.3.1 Introduction

There are numerous types of bridge inspections. Each inspection type has been designed to obtain specific information from a structure. For instance, when a structure is built, an Initial Inspection is done to document the as-built condition of the structure and its structural elements. This is the baseline inspection, and all future inspection findings are compared to this information. Routine Inspections are performed at regular intervals to monitor the working condition of structure elements. This is the most common type of inspection. The results from a Routine Inspection are used to assess structure safety and structure maintenance needs. Special Inspections are used to monitor known defects in a structure and assess completed repairs.

All of the inspection types that are used by the Wisconsin Department of Transportation (WisDOT) help to create a complete picture of a structure's condition and are described in detail in this chapter.

1.3.2 Initial Inspection

1.3.2.1 Purpose

CFR 650.305 states: *Initial Inspection. The first inspection of a new, replaced, or rehabilitated bridge. This inspection serves to record required bridge inventory data, establish baseline conditions, and establish the intervals for other inspection types.*

The initial inspection is the first inspection of a new, replaced, or rehabilitated bridge. The initial inspection serves to record required inventory data and elements, establish baseline conditions, and establish the intervals for other inspection types and activities. The initial inspection is a fully documented inspection, using the structure plans, to determine inventory data about the structure for entry into HSIS. In addition, Nonredundant Steel Tension Member (NSTM) or Underwater Dive inspections that are needed must be performed as soon as practicable, but within 12 months of the bridge being open to traffic. Performing repairs or preservation activities does not prompt a need to perform an initial inspection but may require a Special inspection – see Section 1.3.10.3.

The initial inspection should be completed as soon as practical, preferably before the structure or portion of the structure opens to traffic, but no later than 3 months after opening to traffic. Completing prior to opening to traffic allows for an inspection under more convenient circumstances for both the inspector and the travelling public. This will also assist in completing a punch list for the construction project.

The following is provided to assist with determining if an initial inspection is to be completed.

1. An initial inspection is to be completed whenever any primary structure work concept is completed which includes:
 - Replace Structure
 - Replace Deck



- Replace Superstructure
 - Bridge Widening
 - Raise Structure
 - Replace/Eliminate Joints
 - Replace Bearings
 - Repair Superstructure – Restore Condition & Capacity
 - Repair Substructure - Restore Condition & Capacity
 - Overlay Deck - Concrete
 - Overlay Deck - PPC
 - Structural Reinforced Concrete Overlay
 - Culvert Extension
2. A completed new bridge that is not open to public traffic is not subject to the initial inspection requirement until opened to traffic since it is technically closed.
3. Bridges under construction, closed to traffic or under phased/staged construction, require an initial inspection to be completed within 3 months for any portion of a bridge that opens or reopens to traffic.
- a. Projects with many phases or rapid progression through phases (e.g., nightly or weekend closures), it may not be feasible to complete an initial inspection every time a portion of a bridge opens to traffic. Up to 3 months of construction work may occur and multiple phases might have elapsed before the initial inspection is required. Those portions of the new bridge open to traffic and the bridge members/elements that constitute or carry vehicular live load path are to be inspected.
 - b. An existing bridge being rehabilitated must continue to receive regularly scheduled inspections for any portions open to traffic.

If during construction, a required inspection cannot be conducted due to extenuating circumstances such as a hazardous project site, contact the Statewide Program Manager in advance of when the inspection is due. Preapproval by FHWA is required in advance of the inspection due date plus the tolerance*. Approvals, communications, and circumstances related to the delayed inspection must be documented in the bridge file.

* Tolerance is 3 months for ≥ 24 month interval and 2 months for < 24 month interval.

- c. Consideration should be given to including provisions in construction contracting documents that require the contractor to perform any NBIS inspections due while the construction project is underway.

Open to Traffic: A bridge open to traffic during rehabilitation must continue to have regular scheduled inspections on all portions open to traffic.

Refer to Section 1.1.14 for more inspection information about closed bridges.

Temporary bridges for highway traffic must have an NBIS inspection completed prior to opening to traffic (WisDOT's Standard Specifications for Highway and Structure Construction Section 526). A temporary bridge open to traffic greater than 24 months must be inspected and inventoried at 24 months per the NBIS and data entered in HSIS. A bridge ID for a temporary bridge open greater than 24 months must be assigned per



Chapter 2.5 of the WisDOT Bridge Manual. Upon removal of the temporary bridge, the bridge ID should be marked as REPLACED in HSIS.

Private bridges connected by a public road on both ends must be inventoried and inspected within 3 months of being identified. A bridge ID must be assigned per Chapter 2.5 of the WisDOT Bridge Manual Chapter.

Newly found bridge must have an initial inspection completed within 3 months of the bridge number assigned by WisDOT. The region PM will assign a number once the structure has been confirmed to be a bridge by a certified bridge inspector.

1. An initial inspection include the following actions which are to be completed by the inspection team: Collect structure inventory data required by the SNBI and WisDOT policy.
2. Determine, quantify, and rate new elements and assessments.
3. Review and update existing elements, assessments, and SNBI data items; and code condition ratings when necessary.
4. Determine the appropriate inspection types, activities, and intervals required for the structure and update HSIS based on the guidance provided in the SIM.
5. Photographs and sketches, as required and necessary to detail the initial condition of the bridge.
6. Upon completion of the inspection, notify the responsible PM and construction project manager of the inspection findings including recommended corrections (punch list) and summary of missing file documents.

The initial inspection TL must verify the following information exists or is referenced in HSIS:

1. An existing set of plans, as-builts, shop drawings, and design computations for the bridge.
2. Hydraulic and scour computations and scour vulnerability.
3. An analytical determination of load capacity (performed by a qualified Wisconsin professional engineer).
4. All structure inventory data required by the SNBI and WisDOT policy.
5. Other relevant information required by the department to maintain an accurate bridge file.
6. Baseline structural conditions and element quantities.
7. Record description and location of any construction issues, nonconforming materials allowed to remain, or existing problems in the structure.
8. Location and condition of any NSTM, SRM, and IRM and fatigue details.
9. Structure specific inspection procedures, when necessary.

10. Underwater channel profiles at the upstream and downstream fascia (for structures over water).
11. Using the profile information, assessment of the need for future underwater dive inspections.



Figure 1.3.2.1-1: Inspector Performing an Initial Inspection.

1.3.2.2 Precision

The Initial Inspection is required to document “as-built” **conditions**, not whether the structure was constructed per Plans and Specifications. Since this is a baseline inspection, all deficiencies, cracks, construction errors, alignment problems, etc. should be quantified and documented. The compiled documentation will be used during future inspections to determine if defects discovered in the future existed when the structure was constructed or if they have materialized from the loading applied to the structure.

Inherent Defects

The initial inspection may identify inherent defects which are a characteristic of the material or results from normal construction practices - it is not indicative of damage or deterioration. An inherent defect by itself would not result in a maintenance, preservation, or repair action. In general, describe the inherent defect including the location and extent on the inspection report in the narrative section under the element defect that closely represents the inherent defect and rate as CS1. Some examples of inherent defects are listed below. This is not an all-inclusive list.

1. Poorly consolidated concrete (honey combing) with penetration depth ≤ 1 " without exposed rebar.
2. Chert pop-outs, generally ≤ 1 " depth or ≤ 3 " width.
3. Snowplow/vehicle scrapes/gouges that does not expose coarse aggregate.
4. Grinding of the wearing surface which does not create a loss of friction.



5. Patched areas on the top flanges of prestressed girders from construction framing hangers.
6. Patched holes in the deck surface from parapet forming practices.
7. Patched area in deck or abutment from joint replacement.
8. Rust stains from rebar chairs or forming ties.

Defects that are not inherent to normal construction practices or material characteristics but can be attributed to poor construction practices or poor material qualities are those that would likely lead to future maintenance or preservation actions. Those defects are to be rated for the element in the appropriate CS. Some typical defects resulting from poor construction practices are listed below.

1. Poorly consolidate concrete with penetration depth >1" or with exposed rebar (Delamination/Spall = CS3).
2. Small spalls on the top flanges of prestressed girders from construction framing hangers that are not patched.
3. Damage to girders from handling or the chain tie-downs to the trailers.
4. Dents in the top flanges of girders from deck removals (distortion defect).
5. Chert pop-outs, generally >1" depth or >3" width (Delamination/Spall = CS2).
6. Tight cracks (state size) in prestressed members as delivered or as initially installed. IE end cracks or top flange cracks in wide flange girders.
7. Grinding of the wearing surface which results in loss of friction.

1.3.2.3 Inspection Interval

Each newly constructed or rehabilitated structure shall receive an Initial Inspection as soon as practical but within 3 months of opening the structure to traffic. An Initial Inspection must be completed before the construction contract is finalized.

Below is a list of required bridge inspections conducted after the initial inspection.

Inspection or Activity Interval		
Type	Maximum Inspection Interval (Months)	
	Low Risk	High Risk
Routine	24	12 ⁽²⁾
	48 ⁽¹⁾	
In-Depth	Varies (48 to 72) ⁽³⁾	
Floor Beam identified as SRM, In-Depth	96	24
NSTM	24	12



UW-Dive	60	24
	72 ⁽⁴⁾	
UW-Profile	96	Varies (24 to 60) ⁽⁵⁾
SI&A Review	48	
Scour POA	48	

1. Structure must qualify per section 1.3.3.3
2. Includes bridges that are closed; see section 1.3.12 for more information
3. Interval is dependent on structural detail per section 1.3.4.3
4. Structure must qualify per section 1.3.7.3
5. Dive inspected bridges are on a 60-month cycle per section 1.3.6.1

1.3.3 Routine Inspection

1.3.3.1 Purpose

CFR 650.305 defines a *Routine Inspection* as: *Regularly scheduled comprehensive inspection consisting of observations and measurements needed to determine the physical and functional condition of the bridge and identify changes from previously recorded conditions.*

1.3.3.2 Precision

Routine inspections are generally conducted from the deck, ground, or water level or from permanent work platforms and walkways. If any element of the bridge appears to be distressed, the inspector should take a closer look at that element. Critical load-carrying members (e.g., steel and concrete girders, decks, slabs, concrete box girders, piers and bents, bearings, abutments) should be closely monitored. Fatigue prone details or elements should receive a detailed, close-up (arm's length) inspection. See Section 3.6, NSTM Inspection and Part 2 Appendix D, Fatigue Prone Details for typical critical details. Inspection of underwater portions of the substructure is limited to observations during low-flow periods, probing for signs of undermining, and streambed profile measurements where applicable. This is further discussed in Section 3.9 All inspection results should be fully documented on the report form stored in HSIS.

Any changed or deteriorated structural conditions that might affect previously recorded bridge load ratings should be noted on the inspection form. If the inspector determines that a new load rating is warranted, the "load rating" box should be marked with a "Y". The owner is responsible for rating the structure. That owner is also responsible for getting the updated structure data into the appropriate structure file(s) located in the HSI. The HSI electronic file is the Official Bridge File.

Public safety is the primary concern of the structure inspector. Therefore, the inspector should make sure Wisconsin's structures are physically safe as well as structurally stable. Special attention should be paid to the condition of parapets, railings, pedestrian fencing, guardrail,



sidewalks, spalling concrete surfaces, and other safety related members. The following are examples of conditions that may warrant documentation and notification of the Local, County or Region Manager:

1. trip hazards, severe approach settlement, or large spalls on sidewalks;
2. rebar protruding from decks, walks, or parapets;
3. loose, missing, or damaged railings or parapets;
4. missing or damaged guardrail;
5. loose concrete that could fall onto a traveled way (road, walk, bike path, waterway, or rail line); and
6. any other condition that the inspector perceives as a threat to public safety.

The inspector may have several documents available to assist him in organizing and performing the inspection. These documents include: as-built plans, original shop drawings, as-built repair plans and shop drawings, and previous inspection reports.

1.3.3.3 Routine Inspection Interval

Routine inspections are performed at regular intervals not to exceed (NTE) 24 months. **For high risk bridges the regular interval shall not exceed 12 months.**

High Risk Bridges meeting any of the following criteria must be inspected at intervals NTE 12 months:

- Any of the following condition ratings is coded 4 or less:
 - B.C.01 Deck Condition Rating
 - B.C.02 Superstructure Condition Rating
 - B.C.03 Substructure Condition Rating
 - B.C.04 Culvert Condition Rating
 - B.C.11 Scour Condition Rating
- Bridge is posted less than 40 ton based on load rating.

The routine inspection interval may be reduced by the county or region inspection program manager based on other factors such as element condition ratings, scour environment, history of vehicle impact damage, other known deficiencies, or inspector recommendation.

Bridges with Deck, Superstructure, Substructure, Culvert, or Scour Condition Rating coded four (4) or less due to localized deficiencies, a Special inspection – Isolated Activity may be completed in lieu of a Routine inspection as described in Section 1.3.10.2.

Low Risk Bridges meeting the following criteria are eligible for an extended regular interval of 48 months:

- NBI Deck, Super, Sub, Culvert ≥ 6 or N.



- Must have an initial or routine inspection and another routine inspection 24 months or more apart.
- Span Type – all slab types, all girder types (except thru girder, girder/floorbeam), all box girder - multiple, arch under fill without spandrel, 3 and 4 sided frames only, T-beam, and pipe.
- Span Material – Concrete or Steel
- Inventory Load Rating Factor ≥ 1.0
- Routine Permit Loads = A or N.
- Fatigue Details (E & E') = None
- Cannot have steel defect 1010 Cracking.
- Cannot be load posted.
- Routing Permit Load item = A (routine permit loads are not restricted) or N (no permit loads allowed)
- Cannot have Element 161 Steel Pin, Pin & Hanger Assemblies or Pin thru Web.
- Border bridges with adjoining states are eligible with adjoining state agreement.
- Not a NSTM (fracture critical) bridge
- Hwy Min Vertical Clearance $\geq 14.0'$ (on or under)
- Scour Vulnerability = A or B (stable for scour)
- Scour Condition Rating ≥ 6
- Channel Condition ≥ 6
- Channel Protection Condition ≥ 6
- Must be less than 50 years old.
- No bridges with complex features

The routine inspection interval may be kept at the standard 24-month interval by the county or region inspection program manager based on other factors such as element condition ratings, scour environment, history of vehicle impact damage, other known deficiencies, or inspector recommendation.

For Steel twin-tub girder bridges that were analyzed and found to be no longer NSTM but system redundant member (SRM) bridges shall have a maximum required inspection Interval of 48 months for the interior of the tub girders. The rest of the bridge is to follow the eligible routine inspection Interval. For more information on SRM's see the Redundant Members section in this chapter.

The 48-month extended Intervals is optional and is up to the structures owner to utilize. Local agencies are required to be rated at a level of Compliance or Substantial Compliance for each of the FHWA 23 metrics to be eligible to utilize the extended Interval provisions.

Failure to rate at these levels for any of the 23 metrics will require the local agency to write a Plan of Corrective Action (PCA) to correct the deficiencies. The plan must be approved by the Statewide Inspection Program Manager and Regional Program Manager and the deficiencies must be corrected within the timeline agreed to in the PCA to maintain eligibility.

The structures owner interested in participating in the 48-month extended intervals needs to have the County PM or Commissioner fill out the [DT2002](#) Structure Inspection Quality Control Form and follow the instructions enclosed.



1.3.4 In-Depth Inspection

1.3.4.1 Purpose

An In-Depth Inspection is a close-up, detailed inspection of one or more bridge members located above or below water, using visual or nondestructive evaluation techniques as required to identify any deficiencies not readily detectable using routine inspection procedures. Hands-on inspection may be necessary at some locations. This higher-level inspection can be performed on any structure type, though it is commonly performed on steel superstructure bridges with problematic details that need close up evaluation (as discussed below).

Each bridge requiring in-depth inspections must have documented inspection procedures in the bridge file developed in accordance with Section 4.2 of the MBE. The procedures, whether general or specific:

- o A qualified inspection team leader must be present during the entire in-depth inspection.
- o Identify each bridge member requiring an in-depth inspection and document each location.
- o Detail advanced inspection methods or techniques to be used to fully ascertain the existence of or extent of a deficiency not readily detectable using routine inspection procedures. In many situations, this may be a visual hands-on inspection.
- o Review and update the in-depth inspection interval.
- o Specify any additional qualifications, or specialized training, required of the inspection team leader or specific bridge inspectors (divers, riggers, NDE certified, etc.).
- o Specify needed special access equipment or traffic control.

An In-Depth Inspection can be scheduled independently of a Routine Inspection, though generally at a longer interval, or it may be a follow-up for a Damage Inspection. Generally, specialized equipment is required to obtain the necessary hands-on access to the element (snooper trucks, scissor lifts, ladders, etc.).

It is important to correctly document in HSIS the inspection types and activities performed. It may be practical to perform other inspection types, such as the Routine inspection, concurrently with the In-Depth inspection. An activity such as Non-Destructive Evaluation (NDE) may be completed as part of the inspection. Make sure to select (check) the appropriate boxes in HSIS for all inspection types and activities completed.

For large and complex structures, In-Depth Inspections may be scheduled separately for defined segments of the bridge or for designated groups of elements, connections, or details that can be efficiently addressed by the same or similar inspection techniques. If the latter option is chosen, each defined bridge segment and/or each designated group of elements, connections, or details should be clearly identified in the inspection procedures and inspection specific notes as a matter of record.

Moveable bridges have complex features requiring In-Depth inspections. The electrical and mechanical functional systems are part of the Complex Feature inspection of a movable bridge. See Part 3 for inspection requirements of movable bridges and Section 1.3.13 for inspection guidance for Complex Feature bridges.

The activities, procedures, and findings of In-Depth Inspections should be thoroughly documented with appropriate photographs, test results, measurements, and a written report in



the HSI system. In addition, access methods must be clearly documented so that future scheduling needs can be determined.

WisDOT requires an In-Depth inspection at a defined interval for the structures mentioned in section 1.3.5.3. However, there are other conditions and/or structural details that may prompt an unscheduled In-Depth Inspection.

Several common conditions or structural details that could prompt an In-Depth Inspection (and possibly NDE) include:

- Apparent cracks in steel members
- Apparent cracks, de-bonding or loss of tendon section in a prestressed or post-tensioned member
- Heavily corroded or failed hold down devices.
- Severe section loss in a steel member or primary gusset plate
- Buckled or bent steel girders or beams.
- Welded cover plate end terminations
- Live load bearing anchor pins, and link-bars
- Field welds on tension members
- Intersecting welds, or category D, E, or E' details
- Unique or Problematic Details

The decision to conduct an unscheduled, In-Depth Inspection, with or without the use of NDE, is the responsibility of the Regional Program Manager. Items to consider when making this decision include (but are not limited to) ADT, Condition, Age and Location.

1.3.4.2 Precision

As indicated previously, an In-Depth Inspection is a visual, hands-on inspection of one or more structural elements. Each element under investigation should be within arm's length of the inspector. The inspection may include a recommendation for a load rating to rate the residual capacity of damaged or deteriorated members, depending on the extent of the damage or deterioration. Nondestructive load tests may be conducted to assist in determining a safe bridge load-carrying capacity. The inspector should exercise sound judgment in recommending when a load capacity analysis is warranted.

1.3.4.3 In-Depth Inspection Interval

In-Depth Inspections are **required** for the following:

- Bridges with pin thru web or pin & hanger assemblies (excluding NSTM Structures)



- Steel Bridges with floor systems (excluding NSTM Structures)
- 3 or 4 Chord Deck Trusses

Maximum Required In-Depth Inspection Interval:

Bridge Type (non-NSTM Bridges)	Requirement	Maximum Interval
Pin & Hanger Assemblies	Visual, Hands-on	72 Months
Steel Floor Systems (Floorbeam/Stringer)	Visual, Hands-on	96 Months
3 or 4 Chord Deck Trusses	Visual, Hands-on	48 Months

Other In-Depth inspections can be scheduled to supplement routine inspections, or as a follow-up to a special, initial, or damage inspections. But these will generally not have a recurrence interval.

For In-Depth inspections on structures with pins, a minimum of 20% of the pins shall be evaluated with NDE methods, including all components that have indications of cracking, distress, fretting rust, or seizing. The locations that have been evaluated shall be thoroughly documented, and efforts shall be made in subsequent in-depth inspections to vary the components being tested.

1.3.5 Nonredundant Steel Tension Member (Fracture Critical) Inspection**1.3.5.1 Purpose**

CFR 650.305 defines a Nonredundant Steel Tension Member (NSTM) inspection as: *A hands-on inspection of a nonredundant steel tension member.* An NSTM inspection is a specific type of In-Depth inspection. However, since it is specifically called out in the Code of Federal Regulations, NSTM Inspections must be coded separately from In-Depth inspections on the National Bridge Inventory submittal and in HSI.

CFR 650.305 defines a nonredundant steel tension member (NSTM) as: *A primary steel member fully or partially in tension, and without load path redundancy, system redundancy or internal redundancy, whose failure may cause a portion of or the entire bridge to collapse.*

Common NSTM's include (but not limited to):

- Tie girders on tied arch bridges
- Tension chords or tension diagonals on trusses
- Tension flanges on non-redundant girders
- Tension flanges on non-redundant steel pier cap beams
- Pins on non-redundant girder/truss bridges
- Primary gusset plates connecting NSTM's

- Connecting points of NSTM's chords/diagonals

Primary gusset plates, regardless of connecting NSTM or compression elements, with continuing deterioration (active corrosion, distortion) are risk factors. The locations of these elements, as well as the amount of deterioration shall be measured and documented in the bridge inspection report. The Interval and methods of measurement shall be recorded in the inspection procedures.

NSTM Inspections are regularly scheduled inspections. NSTMs require more thorough and detailed inspections than the members of non-NSTM bridges. In recognition of this, Federal Regulation 23 CFR 650.313(g) requires inspection procedures to be developed and documented for each NSTM bridge.



Figure 1.3.5.1-1: Inspectors Performing a NSTM Inspection

Bridges with NSTMs have written bridge specific inspection procedures and NSTM diagrams which clearly identify the location of all NSTMs, specify the Interval of inspection, describe specific risk factors unique to the bridge, and clearly detail inspection methods and equipment to be employed. Guidance for the specific inspection procedures is provided under Section 1.3.5.4.

An NSTM Inspection can be scheduled independently of a Routine Inspection, though it is common to schedule both during the same inspection. Generally, specialized equipment is required to obtain the necessary hands-on, arm's length access to the element (under bridge inspection vehicle, scissor lifts, ladders, etc.). The first NSTM inspection for a bridge or for a bridge with rehabilitated NSTMs must be completed as soon as possible but within 12 months of the bridge opening to traffic per CFR 650.313(f)(3).

On some bridges, it may be practical to include all elements of the structure during the inspection. In this case, both the Routine and NSTM (Fracture Critical (Arm's length)) boxes shall be checked in the Highway Structures Information (HSI) System when entering the inspection.



For some bridges, the NSTM Inspection may be scheduled and completed separately from the Routine Inspection. If this option is chosen, each defined NSTM shall be clearly identified in the inspection procedures and inspection specific notes as a matter of record.

The activities, procedures, and findings of NSTM Inspections must be thoroughly documented with appropriate photographs, test results, measurements, and a written report in the HSI system. In addition, access methods must be clearly documented so that future scheduling needs can be determined.

Floorbeams spaced greater than 14 feet apart shall have a hands-on inspection for the entire tension portion of the floorbeam. A hands-on inspection also applies to connections located in tension zones, such as the floorbeam connection(s) to the primary load carrying member and connections to secondary members such as stringer to floorbeam. These floorbeams will be inspected using the same techniques as NSTM. This shall be noted in the inspection procedures. The floorbeams shall be inspected at the NSTM inspection Interval for the bridge in question and be conducted by a certified NSTM inspector. When floorbeams spaced greater than 14 feet are shown to be non-critical through analysis (approved by Bureau of Structures), the hands-on inspection is not required and should be inspected with typical visual methods.

In rare cases where arms-length access cannot be safely accomplished by traditional methods (reach-all, ladder, etc.), alternative means of inspection are necessary. These methods require detailed inspection procedures that must be approved by BOS prior to use. Please coordinate with BOS Structures Maintenance prior to developing these procedures.

In addition, if the owner agency has demonstrated that floorbeam members spaced greater than 14 feet apart have system or internal redundancy based on an FHWA approved methodology per CFR 650.313(f)(1)(i), then NSTM procedures are not required for those members.

1.3.5.2 Precision

An NSTM Inspection is a hands-on inspection. CFR 650.305 defines a hands-on inspection as: *Inspection within arm's length of the member. Inspection uses visual techniques that may be supplemented by nondestructive evaluation techniques.* Every square foot of the member/member component is examined. The observations and/or measurements are used to determine the structural capacity of the member/member component, to identify any changes from previous NSTM Inspections, and to ensure that the structure continues to satisfy present safety and service requirements.

Under-bridge access equipment is typically required to move the inspector within arm's length of the members. There may be permanent work platforms and walkways available on some larger structures to aid in inspection work. The access methods used during the inspection must be documented in the inspection procedures.

1.3.5.3 Nonredundant Steel Tension Member Inspection Interval

Nonredundant steel tension members are inspected at regular intervals not to exceed 24-months except as required based on NSTM condition and inspection findings.



NSTM Bridges meeting the following criteria must in be inspected at intervals NTE 12 months:

- NSTM Inspection Condition State is coded ≤ 4

The inspection Interval must be identified in the written inspection procedures.

Maximum Required Inspection Interval:

Hands-on/visual 24 months

Hands-on/visual when NSTM Bridge Inspection Condition Item is coded ≤ 4 12 months

Nondestructive Evaluation (NDE) 72 months

Details to consider for NDE of NSTM Components include:

- Pin and hanger assemblies
- Live load bearing anchor pins and link bars
- Pin thru web assemblies
- Welded cover plate end terminations on NSTM's
- Field welds on NSTM's
- Intersecting welds, or category D, E, or E' details on NSTM's
- Unique or Problematic Details on NSTM's




Figure 1.3.5.3-1: Inspector Performing Ultrasonic Testing for Crack Detection.



1.3.5.4 Specific Inspection Procedures

A bridge identified with a nonredundant steel tension member (NSTM) must have a detailed written inspection procedure specific to that bridge. These inspection procedures are to be kept in the bridge file, reviewed, and updated for **each** NSTM inspection. The inspection procedures should be written in a manner that is useful to the inspection team.

The inspection procedures must address any of the following areas that are relevant to the specific NSTM bridge.

- General Information –
 - Provide a general statement indicating the scope of the inspection
 - Include hands-on visual assessment of identified NSTMs
 - Identify problematic details.
 - Identify the method(s) to be used to complete the inspection.
 - Identify any other inspection types or activities that will be performed at the same time, for example, routine or NDT.
- Clearly specify the Interval of the NSTM hands-on visual inspection.
- NSTM Diagram which identifies the location of the nonredundant steel tension members, primary gusset plates, including any floorbeams needing hands-on inspection. The team lead or inspection program manager should verify the diagram is up to date. Form DT2011 may also be used to document the NSTM diagram.
- Workforce/Staffing
 - Staffing level – number of inspectors, team members
 - Staff qualifications needed
 - Define the duties to be performed by each team member or team of inspectors.
- Inspection Tools
 - Special tools not common to a routine inspection
 - Special lighting needs – if needed
 - Nondestructive testing (i.e. magnetic particle, a dye penetrant kit or ultrasonic testing device).
 - Method of access and equipment needed for hands-on inspection of each nonredundant steel tension member. The minimum size and location on the bridge the equipment will be needed.
 - Rope/rigging
 - Ladders
 - Scaffolding
 - Aerial work platforms
 - Under-bridge inspection truck
- Traffic control needs – on and under including any permits required.
 - Roadway
 - Pedestrian
 - Navigation
 - Railroad
- Scheduling – include any conflicts. Some common conflicts to address are as follows:
 - Daytime inspection times
 - Traffic congestion times
 - Known conflicts under the bridge
 - Railroad or navigation traffic
 - Availability of inspection staff



- Site conditions that impact the inspection
 - NSTM condition
 - Clean surface areas (as necessary) to allow for thorough visual inspection
 - Lighting required to improve visibility
 - Utility attachments
 - Environmental concerns
 - Railroads
 - Safety Concerns
 - Confined spaces
 - Traffic (on and under)
 - Homeless people
 - Night work
- Describe the inspection sequence to inspect the NSTM's.
 - Planned sequence that prevents missing details.
 - Historic sequence.
- Contacts and/or situational awareness communication
 - State and local agencies (DNR, county hwy dept, local municipality)
 - Federal agencies (Coast Guard, FHWA, Army Corp, etc.)
 - Law enforcement
 - Emergency response
 - Adjacent property owners
 - Utility company
 - Media
 - WisDOT Region Communications Manager (WisDOT bridges)
- **Identify specific risk factors** that impact safety or serviceability and problematic details/locations affecting the NSTM. Some possible specific risk factors and problematic details are listed below:
 - Cover plates
 - Primary gusset plates with continuing deterioration (active corrosion or distortion). The locations of these elements, as well as the amount of deterioration shall be measured and documented in the inspection report.
 - Discontinuities resulting in stress risers
 - Bolted/riveted connections present
 - Fatigue and fracture prone details (category D, E and E' details)
 - Triaxial constraint
 - Problematic materials
 - Poor welding techniques
 - Intersecting welds
 - Tack/field/intermittent welds
 - Back-up bars
 - Out-of-plane distortion
 - Retrofits/repairs
 - Existing steel cracking
 - Steel section loss
 - Load posting
 - NSTM Condition item of 4 or less
 - Subject to oversized or overweight loads
 - Historic impact damage
 - Service life (>30 yrs)
 - High ADTT (>5,000)



- NDT (MT, UT, PT, etc.) is required because of existing defect
- Historically significant structure issue.
- Pin/hanger or pin through web connections
- Mechanical fasteners (bolts and rivets)
- Other

NSTM Diagram included with the inspection report and procedures must clearly identify the location of all nonredundant steel tension members.

1.3.5.5 NSTM Supplemental Inspection Form

The nonredundant steel tension member (NSTM) inspection report must include a detailed supplemental inspection form which identifies and documents the condition of each NSTM and AASHTO fatigue detail. The inspection report must provide qualitative and quantitative information concerning the NSTM and fatigue detail. This information is important for several reasons: it can offer insight about the condition of the NSTM, it can provide a history of the bridge, and it can be used to substantiate the thoroughness of the inspection effort. The supplement inspection form will be included with form DT2007 for the NSTM Inspection Report. Links to the supplemental inspection forms are below.

Links to supplemental NSTM inspection forms:

[DT2010 \(Word Document\)](#) & [DT2011 \(Word Document\)](#)

[Supplemental NSTM Inspection Form A \(Excel Spreadsheet\)](#)

[Supplemental NSTM Inspection Form B \(Excel Spreadsheet\)](#)

[Supplemental Steel Girder-NSTM Inspection Form \(Excel Spreadsheet\)](#)

1.3.5.6 Highway Structures Inventory System (HSIS)

The specific inspection procedure and the supplemental inspection form must be uploaded into HSIS on the *Documents/Images* tab. The procedures will be loaded under the *Category of Inspection Procedures* and the supplemental inspection form will be loaded under the Category of NSTM.

1.3.5.7 Redundant Members

System Redundant Member (SRM) and Internal Redundant Member (IRM) Determination

The SRM and IRM policy and procedure contains all elements meeting the requirements of 23 CFR 650.313(f)(1)(i)(B) through (G). Refer to section 24.15 of the Wisconsin Bridge Manual.

Identification

WisDOT has select bridges with steel tub girder members that are classified as System Redundant Members (SRM) For steel tub girders, SRM determination was made in accordance with the “*AASHTO Guide Specifications for Analysis and Identification of Fracture*



Critical Members and System Redundant Members”, including the research and evaluation efforts conducted by Purdue University (Rob Connor) that lead to the development of said guide spec. In addition, there are a number of Integral steel Cross Heads, present on select tub girder structures designated as IRM. Internally Redundant Member determination was made in accordance with the “AASHTO Guide Specifications for Internal Redundancy of Mechanically-Fastened Built-Up Steel Members” Note WisDOT has yet to conduct the analysis on these members, but will do so in accordance with the AASHTO IRM guide spec.

Applicability

This policy applies to bridges that have members designated as SRM or IRM as outlined in the AASHTO Guides. WisDOT SRM or IRM are a select set of bridges with steel tub girders meeting criteria in WBM 24.15.

This policy does not apply to bridges with steel tub girders with any of the following:

- a. The presence of a crack that has not been effectively arrested.
- b. A primary load carrying member in Condition State 4 (CS4)
- c. Unresolved impact damage to primary load carrying members, such as stress risers (cracks, sharp reentrant corners) or large out-of-plane distortion

The discovery of any condition listed above does not automatically revert a bridge with an existing SRM or IRM status to an NSTM. This shall be treated as a structural review and subject to the structural review policy and evaluation criteria below.

Evaluation criteria

The detection of the following defects through inspections after the initial baseline condition used in the SRM or IRM determination do not require a reevaluation of the structure’s redundancy. Engineering judgement is to be used to determine if further action is warranted (e.g. repair or non-SRM analysis to support engineering judgement).

1. CS3 or CS4 distortion in the bottom flange or web of the tub girders in the negative moment region
2. CS3 or CS4 distortion in the bottom flange or web of the exterior diaphragms
3. Section loss < 10% of the gross bottom flange and web in the *negative* moment regions
4. Cracking and section loss of bottom flange and web in the *positive* moment regions
5. Missing bolts and section loss of field splices in the tub girders
6. Cracks distortion, section loss in the external diaphragms and/or missing bolts in diaphragm-to-girder connections
7. Fire damage.



Justification for these allowances is provided by the SRM analysis which included a reserve margin of 15% (the analysis is pass/fail criteria, so the analysis still passed with a 15% increase in demands, so this can be considered inversely that a small loss in capacity will not negate the results of the analysis)

A full reevaluation of the SRM is required if any of the following are met:

1. Loading conditions have changed
 - a. The number of striped lanes has increased
 - b. An increase in the deck dead load greater than the dead load considered in the original SRM analysis
 - i. 10% additional dead load was considered in original analysis of the tub girder bridges
2. Section loss $\geq 10\%$ of the gross bottom flange and web in the *negative* moment regions.
3. Removal of external diaphragms (not allowed).

If a reevaluation/analysis is required, the appropriate sections of the bridge will be defined as NSTM, and those procedures are to be followed until a time at which the structure is restored to its original conditions assumed in the current SRM analysis or the structure is reevaluated through a *new* SRM analysis (which requires FHWA approval).

Design and Construction Details

Modern steel tub girder bridges, specifically those in Wisconsin's inventory that have an SRM status, have been designed and constructed with fatigue and fracture resistant details. Most bridges have been fabricated with high performance steels (HPS) which give the members improved fracture toughness. Those bridges with non-HPS were fabricated with A709 steel per a fracture control plan with zone 2 Charpy V-notch toughness requirements. The integral cross heads, with IRM status, are fabricated with HPS70W. The integral cross heads are readily accessible and can be visually inspected during routine inspections. Newly constructed bridges need to follow the AASHTO guidance to be eligible.

Routine Inspection Requirements

Steel tub girder bridges analyzed and found to be system redundant member (SRM) bridges (no longer NSTM) receive a routine inspection per section 1.3.3.3. Document the access methods, focus areas and conditions to monitor in the bridge specific inspection procedures.

In-Depth Inspection Requirements

The in-depth inspection of SRM bridges with steel tub girders consists of a close-up detailed inspection of the interior and exterior of the tub girders, including the full depth exterior diaphragms. The in-depth inspection will serve to collect and document the existing condition of the interior and exterior of the steel tub girders in greater detail than a typical routine inspection. This may include a hands-on inspection at some locations which will be outlined in the bridge specific procedures for in-depth inspections. The inspection will include a close-up



visual inspection by walking the full-length interior of the steel tub girder and by viewing or accessing the exterior of the steel tub girders, including the exterior full height diaphragms, using binoculars, drones, under-bridge inspection unit, or other access methods sufficiently so the inspector is confident the bridge and element condition can be rated. The in-depth inspection may be completed in conjunction with the routine inspection.

The maximum in-depth inspection interval of steel tub girders for SRM bridges is 48 months. However, in-depth inspection interval is the lesser of 24 months or the eligible routine interval when any of the following occurs on the interior of the tub girder:

- Steel cracking or distortion defect exists in CS2, 3, and 4.
- Corrosion or Connection defects exist in CS3 over 5% of total Steel Closed Web/Box Girder element length in any one span. *For example, a 150' twin-tub girder span could have a maximum of $5\% \times 300' = 15$ LF total combined CS3 corrosion or connection defect in that s*

pan before being subject to a reduced interval for the interior inspections.

Special Inspection Requirements

Refer to the special inspection section 1.3.10.

Specific Inspection Procedures

The in-depth inspection for SRM and IRM bridges require detailed written inspection procedures specific to the bridge. These inspection procedures are to be kept in the bridge file, reviewed, and updated for each in-depth inspection. Refer to Section 1.3.5.4 Specific Inspection Procedures for applicable information required in the redundant member specific inspection procedures. Additionally, address the following within the inspection procedures:

- Identify specific areas of concern/risk factors
 - Full-depth diaphragms
 - Review section 1.3.5.4 for additional applicable risk factors

1.3.6 Underwater Profile Activity

1.3.6.1 Purpose

Underwater profile activity involves gathering streambed elevations and alignment information used to assess streambed conditions and monitor channel movement at bridges and bridge like structures over waterways. The data gathered is compared to as-built information and past profiles. The survey is in the form of an underwater profile or a hydrographic survey. The underwater profile consists of cross-sections of the streambed taken parallel to the bridge. At a minimum, profiles must be obtained at the upstream and downstream fascia. It is not required to profile around substructure units (as these are covered by the underwater probe and/or Dive



Inspections), but this may be done during the profile activity as directed by the inspection team leader or the inspection program manager.

Adequate information on the stability of the waterway and an assessment of the risk to a bridge from scour can be achieved by gathering streambed elevations and alignment information through an underwater profile activity or hydrographic survey. Records must be maintained for a historical comparison to determine the extent of any scour, channel shifting, degradation, or aggradation of the channel.

Scour is the movement of channel bed material by the action of the moving water. This movement may result in degradation, or erosion, of material as well as aggradation, or accumulation of material. Degradation of the channel bed may lead to structure instability, posing an often-unseen threat to safety.

There are three forms of scour that can affect the safety of bridges and waterfront structures.

1. General scour is the general degradation or loss of the bed material along a considerable length of a waterway. It can be the result of natural erosion, mining activities, construction, or other events.
2. Contraction scour involves the removal of material from the bed and banks across all or the majority of the width of a channel. Contraction scour is caused by a reduction in the upstream channel cross-section, which results in increased flow velocities, increased bed shear stresses, and subsequent loss of material.
3. Local scour is the removal of material from a smaller area and is restricted to a minor portion of the width of the channel. The main mechanism of local scour is the formation of vortices at the base of piers, piles or other substructure elements as a result of currents, propeller wash, discharge/intake pipes, or other factors.

As discussed in Section 1.3.8, divers should note any signs of scour during underwater inspections. An important assessment during any inspection is how much of the substructure foundation is exposed when compared to design plans.

The inspector should check for scour at every structure over a waterway. The inspector should be aware that scour is generally most severe during periods of high flow¹ and when flows recede to normal levels; the presence of scour is often covered up with silt or timber debris, making detection difficult. Comparison of previous profiles is typically needed to detect and assess general and contraction scour.

¹ High flows following a major rainfall event can generally be expected to occur about 12 hours after precipitation ceases as a rough rule of thumb; however, every waterway is different, based on a variety of factors.



Figure 1.3.6.1-1: Local Scour at the Base of an Abutment.

The ability to capture the true picture of the underwater landscape with an underwater profile is limited. A hydrographic survey is performed in conjunction with the underwater dive inspection using sonar equipment on select bridges. Generally, a hydrographic survey is completed on bridges over larger bodies of water where the water stretches across the full span or multiple spans and boat access is necessary and possible.

The profile may be completed by a TM trained by a TL or PM. A review of the TM's work must be completed by a TL or PM. The results of the profile must be compared with historical data to ascertain potential movement of the channel and risk of substructure undermining. If potential movement of the channel and risk of substructure undermining exists, this may be considered a critical finding and require notification to the Statewide Program Manager. See Section 1.7 for the Critical Finding Procedure and Documentation.

The results must be entered into HSIS with documentation that show or explain the profile. The HSI system will allow the uploading of numerous file formats including Excel spreadsheets. At the inspector's discretion, a spreadsheet may be created for a structure and uploaded to the HSI system for future reference and modification, if necessary. Example template spreadsheets can be utilized on our [website](#) under Inspection Sketches and Templates.

Closed cell structures, such as box culverts and pipes do not require underwater profiles. However, channel probing for scour at the end of a floor or apron is required during the routine inspection. Document findings from probing and channel movement concerns or conditions on the Underwater Probe Form in the inspection report.

Additional requirements and recommendations for when the underwater profile activities are to be performed can be found in Section 1.3.7.

Underwater Profiles in Conjunction with Underwater Dive Inspection

Structures requiring underwater dive inspections will have a "global area" underwater profile activity performed at the bridge during the dive inspection including the following information:

1. Underwater profile activity and global area photographs up and downstream



- a. Underwater profile at up and downstream fascia
 - a. Bottom elevations at sufficient intermediate points between substructure units to adequately determine the top and bottom banks of the waterway, the thalweg of the waterway, and any significant waterway elevation changes.
 - b. Maximum water depth measurements at each substructure unit in the water.
- b. The lateral movement of the channel up and downstream will be monitored by the following method:
 - a. Review existing arial photographs to compare to the field conditions.
 - b. Take up/downstream photographs of the channel and conditions from the bridge deck or channel banks.
 1. Capture enough photos to capture an upstream and downstream view of the entire flood plain; Keeping he bridge rail in the picture allow for consistent photos and determining angle of attack of waterway; or
 2. Overhead photographs up and downstream of the entire flood plain using a UAV (drone).
 - c. Document signs of lateral movement or changes in the channel
2. Hydrographic surveys can be performed in lieu of an underwater profile activity based on the determination of the PM. If a hydrographic survey is performed, then generate fascia cross sections to include in the inspection report. The following guidance can help to determine when to choose a hydrographic survey:
 - a. Generally, performed on bridges over larger bodies of water where the water stretches across the full span or multiple spans.
 - b. Locations of bodies of water that are best surveyed using a boat for access.
 - c. Locations that typical methods of channel survey would be impractical.
 - d. Locations where monitoring lateral stream migration by review of new and historical photographs is not sufficient to ascertain channel condition/movement. Include the global area photographs when the hydrographic survey is completed.

1.3.6.2 Precision

Hydrographic survey data is used to evaluate trends in channel bottom movement and to compare channel bottom elevations to footing elevations. Water depth measurements should typically be recorded to the nearest tenth of a foot. However, scour evaluations are typically



based on changes in elevations greater than 0.5 foot since most channel bottoms are irregular surfaces with random cobbles, debris, and sand ripples.

It is generally an acceptable practice for scour inspectors to measure the water depth relative to the water surface, in waterways without steep profiles or obvious hydraulic drops, assuming the waterline elevation in most waterways is constant over the surveyed area adjacent to the bridge. In actuality, since water always flows toward a lower topographic elevation, it is common for there to be at least 0.1 foot decrease in water surface elevation over a length of 500 feet in most waterways in Wisconsin. For waterways with steep profiles or obvious hydraulic changes in the water surface elevation, all water surface elevations must be recorded if direct water depth measurements are taken. Rather than documenting several water surface elevations, the inspector may choose to record the channel bottom elevation to a constant elevation using a surveyor's level or total station equipment.

During all underwater surveys, the water surface elevation shall always be referenced to a known elevation on or near the bridge.

In most instances, a bridge profile is located on a tangent or vertical curve. In order to expedite the streambed profile, the Wisconsin DOT recommends determining the elevation of an accessible bridge component. For example, the top of a bridge rail, or edge of deck are common landmarks an inspector can utilize when taking streambed elevations. The purpose of the profile is to observe changes to the streambed from inspection to inspection. So long as every inspector subsequently uses the same landmark and elevation for data recording, an accurate account is developed. Therefore, it is imperative that the inspector clearly identify the elevation of the landmark (these can be derived off existing plans or arbitrarily chosen) and the location the measurements are taken from (e.g. North Abutment – Upstream Fascia at Centerline of Bearing). When using an arbitrary elevation, the inspector may assume a constant elevation along the length of the structure, even if located on a vertical profile. Again, this is acceptable because the profile is a comparative tool. So long as the subsequent inspections replicated this arbitrary elevation and the locations at which measurements are taken, the data shall indicate whether there have been any changes to channel alignment or elevation.

While the true streambed elevation determined may be skewed due to the bridge profile following a tangent or vertical curve, the data will be able to be compared to later inspections.

1.3.6.3 Inspection Interval

1. All structures over water except 4-sided structures (i.e. box culverts and round/elliptical pipes) are required to have an initial underwater profile activity completed during the Initial Inspection with subsequent underwater profiles completed at a maximum interval of 96 months.
2. Bridges with a concrete floor for the streambed, other than culvert type bridges, require only an initial profile activity completed. The profile elevations should be obtained along the end of the concrete floor. If the concrete floor runs beyond the right-of-way, the initial profile can be taken along the bridge soffit.
3. Higher Risk Bridges are those meeting the criteria below. These bridges have the underwater profile activity completed at a maximum 24-month interval.



- a. B.C.09 Channel Condition Rating ≤ 4 (poor)
- b. B.C.10 Channel Protection Condition Rating ≤ 4 (poor)
- c. B.C.11 Scour Condition Rating ≤ 6
- d. B.AP.03 Scour Vulnerability = C, D, E, or U (bridge is scour critical)
- e. B.AP.04 Scour Plan of Action = A scour POA is required but not implemented (N) or scour POA is required and implemented (N).

Structures that require underwater dive inspections will have Global area profiles at the required dive interval and can forgo the requirements of Section 1.3.6.3(3). Evidence of channel movement, degradation, or aggradation may necessitate more frequent Global area profiles based on the recommendation of the dive inspection TL. However, dive inspection TL should recommend to the PM more frequent Global area profiles be scheduled if there is evidence of channel movement, degradation, or aggradation.

1.3.6.4 Equipment

Several water depth measurement methods, with a variety of equipment, can be used during a scour inspection with a hydrographic survey. These water depth measurements, often called soundings, can be obtained by manual means (lead line or sounding pole) or technological equipment (fathometer, sonar, radar, etc.). Refer to Chapter 19 in Part 5 for information on underwater profile equipment.

1.3.7 Scour Monitoring Activity (Scour Monitoring Inspection per SNBI)

Nearly all bridges which cross waterways have some vulnerability to scour damage caused by a flood event. A scour monitoring activity is intended to ensure monitoring for structure stability and stream instability during and after a flood event.

A scour critical bridge requires an implemented scour plan of action (POA) (see section 1.3.18) which details the monitoring when triggered by a flood event. A scour monitoring activity is required when flood conditions are reached as described in an implemented POA. At a minimum, the scour monitoring activity must include a post-flood activity of cross sections (profile) and probing after a significant flood event. Document and record the activities in HSIS as a Scour Monitoring Activity and a UW-Profile Activity.

A scour monitoring activity is also required at any bridge where there are signs of channel movement, degradation, or aggradation during or after a flood event.

A scour monitoring activity is recommended for any bridge over a waterway when the bridge experiences any of the following:

- A flood event when the bridge or the roadway approach is overtopped. *
- A river system reaches flood state at a bridge. *
- The presence of highwater flow velocities which could cause scour.
- If determined by the bridge owner or inspection program manager.

The National Weather Services' [Advanced Hydrologic Prediction Service](#) provides flood predictions and flood stages for river systems.



A scour monitoring activity typically involves documentation and actions during and after a flood event by an individual assigned by the PM, TL, or bridge owner (or owner's representative). The inspection activity must be completed by a competent TM under the guidance and coordination of the PM or TL. A review of the TM's work must be completed by the PM or TL. The findings must be documented in HSIS as a scour monitoring activity. Multiple visits to the same bridge during a flood event as part of the scour monitoring can be recorded as a single scour monitoring activity. The start date is the first day the bridge is observed for an event and the end date is the day of the final post-flood survey or activity.

A scour monitoring activity includes the appropriate activities and documentation listed below to ascertain the extent of scour and channel movement:

- Underwater profile at the up and downstream fascia (see Section 1.3.6 for information about underwater profile activity).
 - When required as part of an implemented scour POA for a triggering flood event.
 - Recommended at a bridge over water when the bridge experiences a flood event.
- Underwater probing around the substructure units
 - When required as part of an implemented scour POA after a triggering flood event.
 - Recommended post-flood for bridge units in 4' or less water when the bridge experiences a flood event, to determine the extent of any scour.
- Record of observations including photographs
 - Flood monitoring record or log entered into HSIS – a spreadsheet log is recommended for ongoing or prolonged monitoring. Document in the Inspection Specific Notes section of the inspection report for simple monitoring.
 - Photographs to record condition, changes in condition, and maintenance actions.
- Recommended maintenance actions.

Special/Damage Inspection – a flood event may require review of condition assessments or ratings for elements or components affected. These inspections must be completed by a TL.

1.3.8 Underwater Dive Inspection

1.3.8.1 Purpose

CFR 650.305 defines an underwater inspection as: *Inspection of the underwater portion of a bridge substructure and the surrounding channel, which cannot be inspected visually at low water or by wading or probing, and generally requiring diving or other appropriate techniques.*

Underwater Dive Inspections are a necessary part of an effective structure management program and are mandated by the Federal Highway Administration (FHWA) on routine intervals. Underwater dive inspections should be completed in accordance with OSHA 29 CFR 1910 SUBPARTS T AND Y, and the requirements described in this section. An underwater dive inspection is required if water conditions exist at the structure that prohibit access to all



portions of an element by visual or tactical means ensuring a level of certainty during Routine Inspections. If probing or observations of the substructure elements for scour or deterioration cannot be completed during low-flows (water depths 4' or less), then an underwater dive inspection is required.

These specialized inspections serve an important part in protecting the public, providing reliable service, and reducing maintenance and construction costs. Structural conditions above water that could lead to failure, loss of life or property damage are often observed well in advance by inspectors, maintenance workers, and sometimes even passing motorists. Conversely, significant underwater structural conditions cannot be observed by these individuals until the defect has progressed to the point where distress is evident above water. Unfortunately, structures exhibiting significant underwater defects often collapse before the distress is evident above water.

Although each type of material has predominant mechanisms of deterioration, the environment (moderate temperatures, moisture, oxygen, and chlorides or other chemicals) at the waterline is most conducive to all forms of deterioration. Furthermore, unique mechanisms, such as bacterial corrosion, are also common near the waterline on structures. This deterioration and distress may not be recognizable from above water, nor can the extent and severity be determined in most cases without inspecting the underwater elements.

Underwater profile requirements in conjunction with underwater dive inspections can be found in Section 1.3.6.

1.3.8.2 Precision

Due to limited underwater visibility, the inherent access restrictions of the underwater environment, and the presence of marine growth, the required underwater diving inspection precision depends on the level of effort. Three underwater diving inspection intensity levels are defined by the FHWA. The expected underwater diving inspection precision is based on the individual coverage percentage of these three levels of effort. A summary is provided in Figure 1.3.8.2-1 with narrative descriptions of each level following the figure.

Level	Purpose	Typical Detectable Defects/Expected Findings			
		Steel	Concrete	Timber	Composite
I	General visual/tactile inspection to confirm as-built condition and detect severe damage	Extensive corrosion and holes Severe structural damage	Major spalling and cracking Severe reinforcement corrosion Broken piles	Major loss of section Broken piles and bracings Severe abrasion or marine borer attack	Permanent deformation Broken piles Major cracking or structural damage
II	To detect surface defects normally obscured by marine growth	Moderate structural damage Corrosion pitting and loss of section	Surface cracking, spalling, erosion Rust staining Exposed reinforcing steel and/or prestressing strands	External pile damage due to marine borers Splintered piles Loss of bolts and fasteners Rot or insect infestation	Cracking Delamination Material degradation

Level	Purpose	Typical Detectable Defects/Expected Findings			
		Steel	Concrete	Timber	Composite
III	To detect hidden or interior damage, evaluate loss of cross-sectional area, or evaluate material homogeneity	Remaining thickness of material Electrical potentials for cathodic protection Change in material properties	Onset of reinforcing steel corrosion Internal voids Change in material properties	Internal damage due to marine borers (internal voids) Decrease in material strength Change in material properties	Change in material properties

Figure 1.3.8.2-1: Summary of Intensity Levels.

Level I Effort

An inspection involving a visual examination or a tactile examination using large sweeping motions of the hands where visibility is limited. Although the Level I effort is often referred to as a “Swim By” inspection, it must be detailed enough to detect obvious major damage or deterioration due to overstress or other severe deterioration. It should confirm the full-length continuity of all members and detect undermining or exposure of normally buried elements. A Level I effort may also include limited probing of the substructure and adjacent channel bottom. Refer to Figure 1.3.8.2-2 for a view of a structure during a Level I effort.



Figure 1.3.8.2-2: Inspector Conducting a Level I Inspection Effort.

Level II Effort

A Level II effort is a detailed inspection that requires marine growth to be removed from portions of the structure. Cleaning is time-consuming so there is a need to limit the detailed inspection to a representative sampling of components. For piles, a 12-inch high band should

be cleaned at designated locations, generally near the waterline, at the mudline, and midway between the waterline and the mudline. On an H-pile, marine growth should be removed from both flanges and the web. On a rectangular pile, the marine growth removal should include at least three sides; on an octagonal pile, at least six sides; on a round pile, at least three-fourths of the perimeter. On large diameter piles, three feet or greater, one-foot squares should be cleaned at four locations approximately equally spaced around the perimeter, at each elevation. On large solid faced elements such as pier shafts, one-foot squares should be cleaned at four random locations, at each elevation. The Level II effort should also focus on typical areas of weakness such as attachment points and welds. The Level II effort is intended to detect and identify damaged and deteriorated areas that may be hidden by surface biofouling. The thoroughness of cleaning should be governed by what is necessary to discern the condition of the underlying material. Removal of all biofouling staining is generally not required. Refer to Figure 1.3.8.2-3 for a view of a structure during a typical Level II effort.



Figure 1.3.8.2-3: Inspector Conducting a Level II Inspection Effort.

Level III Effort

A detailed inspection typically involving nondestructive evaluation (NDE) or partially-destructive evaluation (PDE), conducted to detect hidden or interior damage, or to evaluate material homogeneity. Typical inspection and testing techniques include the use of ultrasonic, coring or boring, physical material sampling, and in-situ hardness testing. Level III testing is generally limited to key structural areas, areas which are suspect or areas which may be representative of the underwater structure. Refer to Part 5 of this Manual for additional information on nondestructive and partially destructive evaluation. Also, refer to Figures 1.3.8.2-4 and 1.3.8.2-5 for views of inspectors conducting Level III efforts.




Figure 1.3.8.2-4: Inspector Using a D-Meter to Conduct a Level III NDE Inspection Effort.



Figure 1.3.8.2-5: Inspector Using a Drill to Conduct a Level III PDE Inspection Effort.

1.3.8.3 Underwater Dive Inspection Interval

CFR 650.311(b) establishes the minimum requirements for underwater inspection interval. These requirements are described and elaborated on in the *NBIS Metrics for Overview of the National Bridge Inspection Program*.

Underwater Dive Inspection Interval:

Wisconsin requires adherence to the following criteria :



1. An underwater profile is required as part of the Initial inspection.
2. An underwater dive inspection must include at least a Level I effort on 100 percent of all underwater elements, a Level II effort on 10 percent of all underwater elements, and a Level III effort as determined by the TL or PM.

Lower risk bridges -

UW inspections are performed at regular intervals not to exceed (NTE) 60-months, or NTE 72-months when adhering to FHWA approved UW criteria. The criteria a structure must meet to be considered for the 72-month Routine UW-inspection Interval are as follows:

- B.C.09 Channel Condition ≥ 6 (satisfactory)
- B.C.10 Channel Protection Condition ≥ 6 (satisfactory)
- B.C.11 Scour Condition Rating ≥ 6 (satisfactory)
- B.C.15 Underwater Inspection Condition ≥ 6 (satisfactory)
- B.AP.03 Scour Vulnerability item = A or B (stable for scour)
- Structure must have at least two (2) Underwater Dive inspections on file to be eligible.
- Border bridges with adjoining states are eligible with adjoining state agreement.
- No bridges with complex features
- No substructure Elements with the Microbial Induced Corrosion Defect (8901).
- No substructures with timber substructure elements are eligible.
- Must be less than 50 years old.

The 72-month extended UW-Inspection Intervals is optional and is up to the structures owner to utilize. The eligibility requirements are the same as previously describe for the 48-month routine inspections. The structures owner interested in participating in the 72-month extended UW-inspection Intervals needs to have the County PM or Commissioner fill out the [DT2002](#) Structure Inspection Quality Control Form and follow the instructions enclosed.

High risk bridges –

Bridges meeting the following criteria must be inspected at a reduced interval not to exceed 24 months:

- B.C.09 Channel Condition ≤ 3 (serious)
- B.C.10 Channel Protection Condition ≤ 3 (serious)
- B.C.11 Scour Condition Rating ≤ 3 (serious)
- B.C.15 Underwater Inspection Condition ≤ 3 (serious)
- B.AP.03 Scour Vulnerability = 0, C, D, E, or U
 - C or D = bridge is scour critical
 - 0 or E = scour appraisal has not been completed
 - U = bridge has unknown foundation

Partial underwater inspections may be completed on bridges meeting the reduced interval criteria for the underwater inspection due to localized deficiencies. The inspection program manager, with concurrence from the bridge owner, may request



from the SPM, approval to complete a partial underwater inspection on the element(s) contributing to the condition rating of 3 or less. The request, including the reason for the exemption and the inspection procedure for the partial inspection must be provided to the SPM at least 2 months prior to the month the inspection is due. Bridges granted the partial underwater dive inspection by the SPM will have the inspection results entered in HSIS as an Underwater inspection with only the inspected elements checked, with the inspection procedures for the partial inspection, and with the documentation showing SPM approval. A full underwater dive inspection must occur on a 24-month interval.

1.3.8.4 Methods of Underwater Dive Inspection

After identifying that a structure requires an underwater diving inspection, it must be decided which underwater diving inspection method should be used. Underwater diving inspection methods are categorized as “manned” or “unmanned”. The following factors influence the determination of which method of underwater diving inspection is best suited for a structure:

1. Water depth (depth greater than 4 feet should be performed by diving)
2. Water visibility
3. Water velocity (if greater than 2 feet per second, should be performed by diving)
4. Streambed conditions (if soft or irregular, should be performed by diving)
5. Presence of debris or other obstructions/obstacles
6. Substructure configuration

The qualified “manned” methods consist of an inspection-diver using commercial Self-Contained Underwater Breathing Apparatus (SCUBA) equipment or surface supplied air (SSA) equipment. For qualified “manned” methods, the Team Leader is required to be a certified diver and be able to perform the underwater inspection.

The “unmanned” methods typically use a real-time submersible videography lens or electronic imaging devices to transmit observation data to a qualified Team Leader. Although electronic imaging devices are not often used in Wisconsin, submersible videography lenses have been used on telescopic poles and in remote operated vehicles (ROVs). When the diver is not a qualified Team Leader and the Team Leader is not a qualified diver, the lenses can be attached to a diver’s helmet. While these “unmanned” methods are acceptable if they are conducted in a way that ensures a sufficient level of certainty, they should be considered only as a secondary alternative if the more preferable qualified “manned” method is not feasible. The Team Leader’s assessment capabilities are adversely affected when unable to perform the actual physical inspection.

Underwater diving inspection in Wisconsin is most frequently conducted by a dive team using SCUBA equipment. This method consists of using a standard exposure suit and a portable air tank. The inspector(s) will make a visual and tactile evaluation of the substructure units by swimming around the individual units. SCUBA equipment allows the inspector greater freedom of movement, the ability to visually inspect the substructure units both above and below the

waterline, even in poor water visibility, and to reach all areas even in deep water. Limitations of the SCUBA method are: the duration of the inspection due to a limited air supply (dive should typically be finished prior to a pressure gauge reading of 750 psi); a permissible depth range for safe operation (120 feet); additional tethering in swift currents; and specialized training and equipment for the inspectors. Refer back to Figures 1.3.8.2-2 to 1.3.8.2-5 for views of inspectors using scuba equipment.

Although more common in underwater diving construction, an underwater diving inspection can also be conducted by a dive team using a surface supplied air system. The equipment consists of a standard exposure suit, a full-face mask/helmet, and umbilical cords connecting the diver to the surface. The inspector(s) will make a visual and tactile evaluation of the substructure units by swimming around the individual units. This method of inspection provides many of the same benefits as a SCUBA inspection along with being well-suited for adverse diving conditions, such as swift velocities (typically up to 14 fps), polluted water, and long diving durations. Limitations of the surface supplied air method is that the equipment: limits free movement; a permissible depth range for safe operation (220 feet), and specialized training and equipment for the inspectors. Refer to Figure 1.3.8.4-1 for a view of an inspector using surface-supplied-air equipment.



Figure 1.3.8.4-1: Inspector Using Surface-Supplied Air Equipment.

1.3.8.5 Inspection Equipment and Tools

The underwater diving inspectors will require a larger than normal amount of equipment to complete the various tasks associated with the structure investigation regardless of the method used. These items are a mix of common tools and specialized equipment that will provide a



breathing medium, means of movement, and aid the inspector in collecting data at the structure.

Personal Equipment

For an underwater diving inspection, a brief equipment list is as follows:

1. Exposure suit (wet or dry)
2. Dive mask or helmet
3. Breathing apparatus
4. Air supply (portable tank or surface compressor unit)
5. Weight belt
6. Dive fins
7. Buoyancy compensator
8. Depth gauge / pressure gauge (All dives should be terminated at 750 psi.)
9. Wristwatch
10. Light source

Furthermore, an inspector conducting a diving inspection should carry additional equipment such as a knife and reserve air tank or J-valve on the tank.

Access Equipment

While access is often gained from the shoreline, some structures are best accessed by use of a boat. Typically, an 18-foot or larger vessel can safely carry the equipment and crew. On some occasions, access may be gained from the structure itself.

Communication Equipment

While it is not mandatory to be in voice communication during shallow water dive inspections, two-way voice communication greatly aids in the efficiency of the inspection data collection and recording, and it provides an added level of safety. For deep-water inspections, the use of two-way voice or hand-signal communication is recommended. The advantages of direct voice communication are:

1. The diver can communicate directly with the note-taker to describe the location, type, and size of any observed defects.
2. The diver can discuss any observations with surface personnel.
3. When using video equipment, the surface personnel can direct the diver to specific areas that appear suspect or where closer investigation needs to be conducted.



4. The diver can immediately report the extent of any problems.

Tools

The inspection team should have access to the appropriate tools and equipment as warranted by the type of inspection being conducted. A number of tools should be available to the inspector and can be categorized as hand-tools or power-tools. Since power-tools are not frequently used, a brief list of typical hand-tools is as follows:

1. Ruler
2. Calipers
3. Probe (ice picks, awls, screwdrivers, etc.)
4. Geologist hammer
5. Scraper
6. Wire brush
7. Pry bar

Testing Equipment

Often an inspection requires some level of material testing to ascertain the condition of the substructure unit that may not visually show any significant signs of deterioration. Testing is also the main component of a Level III inspection. Testing may be either nondestructive or partially destructive and is described in detail in Part 5 of this Manual. Nearly all the methods in Part 5, which are applicable for use on substructures, can also be performed underwater.

Photography & Videography Equipment

A still or video camera can provide a visual record of defects or deterioration that is observed by the inspector. This information can be reviewed with others to better define and evaluate the significance of the defect.

A still camera can be fitted with a variety of lenses and flash units that are suited for different conditions. In low visibility, the camera will need to be placed close to the object and will require a wide-angle lens. Particles that are suspended in the water, which make it cloudy, reduce ambient light and can reflect light from the flash unit into the lens. When visibility is very low, clear water boxes can be used. A clear water box is constructed of clear plastic and is filled with clean water. By placing the box against the object to be photographed, the box of clean water will displace the murky water allowing for a clear photograph. Refer to Figure 1.3.8.5-1 for a view of a typical clear water box.



Figure 1.3.8.5-1: Inspectors Attaching a Clear Water Box to an Underwater Camera.

Video equipment is generally available as self-contained submersible units, or as a submersible camera lens attached to the diver with a cable connection extending to a surface monitor and controls. The latter allows a surface operator to direct the shooting, control the lighting and focusing, and communicate with the diver to obtain the optimum image. A soundtrack could also be dubbed with the video image by the diver or topside personnel to provide a running commentary pertaining to the observations.

1.3.8.6 Underwater Dive Inspection Procedures

A bridge that receives an underwater inspection must have a detailed written inspection procedure specific to that bridge. These inspection procedures are to be kept in the bridge file, reviewed, and updated for **each** underwater inspection.

The inspection procedures must address any of the following areas that are relevant to the specific bridge receiving the underwater inspection.

- Clearly Identify the location of all underwater elements and assess all units during the dive inspection.
 - Dry units can be documented as “dry” without additional detail.
 - Units that can be probed shall be and notes shall be taken on the condition of the streambed and substructure unit.
 - Units require diving shall be inspected according to guidelines in the SIM.
- Specify the interval of the underwater inspection.
- Describe any specific risk factors.
 - The specific risk factors shall be separated into Diver and Structure risk factors.
 - **Diver Risk Factors**



- For each bridge, include diver risk factors (diver safety) in a separated paragraph under the Inspector Site-Specific Safety Considerations section of the report. Start the paragraph “Diver risk factors:”. If there are no diver risk factors, please note “Diver risk factors: None”.
- Some diver risk factors could be:
 - Debris accumulation
 - Limited visibility in the water
 - Rapid stream or current
 - Soft or unstable streambed or stream banks for walk in entry.
 - Pollutants in water

Note this is not an exhaustive list so others may qualify as diver risk factors.

- **Structure Risk Factors**

- Include all structure risk factors (related to scour, environment, or structure) at a bridge in the specific procedures section of the dive inspection report. Provide a separated section of the procedure to address structure risk factors. This section should be started with “Structure risk factors:”. List or describe the structure risk factors. If there are no structure risk factors, please note “Structure risk factors: None”. Remove any structure risk factors listed elsewhere outside of the UW-Dive specific procedures section or separate documents since they should only be listed in UW-Dive specific procedures section of the report.
- Some structure risk factors could be:
 - Debris accumulation
 - Rapid stream or current
 - Pollutants in water
 - Marine environment
 - Meandering channel
 - Unknown foundation
 - Scour critical bridge
 - Observed scour

- Environmental conditions (i.e. MIC for steel, timber piling – limnoria) which may accelerate deterioration.

Note this is not an exhaustive list so others may qualify as structure risk factors.

- Clearly detail inspection methods
- Equipment and tools to be employed.

1.3.9 Underwater Probing

This method of underwater inspection involves either wading or probing with a rod or the feet. Underwater probing is the most basic type of underwater inspection activity and can often be performed by an inspector wading in the water with no additional training. Underwater probing activity is required for all structures over water that are not dove at regular intervals and should be done in conjunction with the Routine inspection.

Underwater probing activity is conducted by evaluating the substructure units and the waterway by using a probe rod or sounding pole. The inspector wearing waders (or a dry/wet suit) walks around the substructure, probing the units and channel bottom with the rod and with his/her feet, while visually inspecting the areas above and directly below the waterline where visibility permits. Limitations of the wading inspection are deep water, poor water visibility, excessively soft or irregular streambed conditions, and swift currents that make movement difficult or dangerous. Refer to Figure 1.3.9-1 for a view of an inspector conducting a wading inspection.

The results of the probe are entered into the HSI system when an inspection type is created under the Tab titled Underwater. This tab lists all substructure units on the bridge. If the substructure unit is dry at the time of the probing, the inspector shall note that on the form for the unit in question.




Figure 1.3.9-1: Inspector Conducting a Wading Inspection.

**1.3.9.1 Inspection Equipment and Tools**

Personal equipment typically includes hip waders, a hard-hat, reflective vest, and tool belt for an inspector conducting an underwater probing/visual (wading) inspection.

1.3.9.2 Underwater Probing Activity Interval

Underwater probing is required to be performed as part of the routine inspection, initial inspection, as well as during an underwater dive inspection. If underwater probing activity cannot be performed during the inspection, the inspector has 3 months to complete the underwater probing while the routine inspection type is open in HSI.

1.3.10 Special Inspection**1.3.10.1 Purpose**

A special inspection is scheduled at the discretion of the bridge owner, used to monitor a particular known or suspected deficiency, to monitor special details or unusual characteristics of a bridge that does not necessarily have defects, or update the inventory and inspection data after a completed repair or maintenance action. A TL is required on site for any special inspection whenever a bridge component condition rating(s) (B.C.XX items) is assessed. The following is a list of possible special inspection activities and required inspector qualifications:

Special Inspection Activities and Qualifications

Special Inspection Activity	Minimum Qualifications	Interval
NDE for Timber	Trained in the type of NDE being performed under direction/oversight of a TL (see Specialist under SIM 1.2.3.2).	As needed and determined by the PM
NDE for Steel	Certified or trained in the type of NDE being performed under direction/oversight of a TL (see Specialist under SIM 1.2.3.2).	As needed and determined by the PM
NDE for Concrete	Trained in the type of NDE being performed under direction/oversight of a TL (see Specialist under SIM 1.2.3.2).	As needed and determined by the PM
Isolated Activity - reduced interval in lieu of Routine Inspection	TL	Per SIM 1.3.10.2



Completed Repair or Change in Overburden	TL	Per SIM 1.3.10.3
Special Inspection without Activity	TL	As needed and determined by the PM

*Under direction and oversight means TL may not be on site but provides training and review of TM work.

For special inspections where a TM completes the inspection, the TL must review the report and sign as reviewer in HSIS. If the TL identifies an issue the PM should be notified.

1.3.10.2 Special Inspection – Isolated Activity

Where Deck, Superstructure, Substructure, Culvert, or Scour Condition Ratings are coded four (4) or less due to localized deficiencies, a Special inspection with Isolated activity which is limited to the localized deficiencies can be used in lieu of a Routine inspection (except for buried and single span bridges, see next paragraph). A Routine inspection must be conducted at the appropriate interval.

In general, single span and buried bridges have similar Routine or Special-Isolated inspection resource needs. It may be advantages to complete the Routine inspection instead of a Special-Isolated inspection. This decision is left to the specific bridge's inspection program manager. The intent of the Special inspection - Isolated activity is to focus limited inspection resources on critical needs by not requiring a routine inspection for an isolated/localized deficiency; however, in general, single span and buried bridges have similar inspection resource needs for a Routine or a Special - Isolated inspection.

The following must be updated in HSIS by the PM for a Special Inspection – Isolated activity:

1. The region PM will set the minimum interval to a minimum of 1/2 of the Routine inspection interval.
2. For local bridges, the local PM must request the region PM set the Special inspection - Isolated activity interval to 1/2 or less of the Routine inspection interval.
3. The responsible PM will review and set the Routine inspection interval not greater than 24 months.
4. The responsible PM will include the reason for the inspection, the elements requiring inspection, and any special inspection procedures under the Special Inspection Specific Procedures box of the Notes tab.

1.3.10.3 Special Inspection for Completed Repairs or Overburden Change

Since both the Specification for the National Bridge Inventory (SNBI) and Element Level rating scales are based upon existing structural conditions, repairs may improve the condition ratings



assigned to a structure. Repairs resulting from damage (likely from corresponding damage inspection) or any permanent repair that affects the SNBI rating requires a Special inspection. Maintenance, temporary repairs, or preservation activities would not require a Special inspection. However, when the overburden on a bridge is changed due to a maintenance or preservation activity, a Special inspection must be completed to update the overburden quantity, the element(s) condition states and Condition ratings, when applicable. A Special inspection for a repair or overburden change should be completed within 6 months of the completed action.

1.3.10.4 Special Inspection Procedures

Documented inspection procedures are to be included with the inspection report for special inspections used for monitoring conditions. The report should outline the scope of the inspection and document all findings. It should also detail the reason for the special inspection and make recommendations for condition rating changes, repairs necessary, or future monitoring activities.

1.3.10.5 Special Inspection Interval

In general, Special Inspections are scheduled at the discretion of the individual responsible for structure inspections for the unit of government that owns the structure.

1.3.11 Damage Inspection

1.3.11.1 Purpose

A Damage Inspection is an unscheduled inspection to assess structural damage resulting from environmental factors or human actions. Flood damage, barge impact, and vehicle impact are common examples of events that may call for a Damage Inspection. A team lead qualified inspector will perform a damage inspection. Additional inspector qualifications for damage that may affect bridges with NSTM, SRM, IRM, or underwater elements are as follows:

- For NSTM, SRM, or IRM bridges, if the damage may affect an NSTM, SRM, or IRM member/element, the inspection must be performed by an NSTM TL qualified inspector following NSTM inspection procedures.
- For damage suspected to have occurred to an underwater portion of a bridge in water greater than 4 feet deep, the underwater portion must be completed by an UW Dive TL qualified inspector.

The TL is required to notify the PM with direct jurisdiction over the bridge as soon as possible. The PM is required to sign off as reviewer in HSIS if they were not the inspector no later than 30 days after the inspection is completed. The PM, with consultation with the TL, when necessary, must determine an appropriate inspection interval based on the condition of the bridge.



Figure 1.3.12.1-1: Impact Damage to a Steel Girder Bridge.




Figure 1.3.11.1-2: Failed Wingwall.

1.3.11.2 Precision

The scope of a Damage Inspection should be sufficient to determine whether there is a need for emergency load restrictions or closure of part or all of the structure to traffic. The inspector should also assess the level of effort necessary to repair the damage. The amount of effort expended on this type of inspection may vary significantly and depends on the extent of the damage. If major damage has occurred, inspectors should evaluate fractured and cracked



members, determine the extent of section loss, make measurements for misalignment of members, and check for any loss of foundation support. A structure inspection form should be filled out and submitted for entry into the HSIS database with addenda and pictures, if necessary, with all the information mentioned above. This inspection may be supplemented by a timely In-Depth Inspection to document more fully the extent of damage and the urgency and scope of repairs. Proper documentation, verification of field measurements and calculations, and perhaps a more refined analysis to establish or adjust interim load restrictions are required follow-up procedures. The ability to make on-site calculations to establish emergency load restrictions may be desirable. A particular awareness of the potential for litigation must be exercised in the documentation of Damage Inspections. Therefore, all documentation should be legible and thorough.

1.3.11.3 Damage Inspection Interval

A Damage Inspection is an unscheduled inspection that is performed to determine if significant damage has been done to the bridge. Generally, a law enforcement officer on the site of an accident involving a structure will notify the appropriate individuals and request a Damage Inspection be performed to determine if the bridge should be closed. A Damage Inspection may be followed up by an In-Depth Inspection to document the full extent of the damage.

1.3.12 Service Inspection

1.3.12.1 Purpose

A service inspection is not a required inspection but is scheduled at the discretion of the bridge owner to identify major deficiencies, safety issues, and maintenance actions. It is performed by bridge maintenance or inspection staff under direction and oversight of a TL. The TL is not required to be on site but provides training and review of TM work. The inspections are meant to be performed from the ground and are not intended to be as rigorous as a routine inspection but requires documentation of any follow-up actions in the HSI. It's recommended to enter a service inspection in HSI if the inspector doesn't find anything during a bridge visit. The service inspection can be selected in HSI within the Create tab under Activity type. Document the purpose of your visit under the inspection notes in the service inspection.

1.3.12.2 Service Inspection Interval

It is considered good practice to schedule a service inspection around the half inspection interval on bridges that have a history of safety or maintenance issues and on bridges with a 48-month inspection interval.

1.3.13 Complex Feature Inspection

1.3.13.1 Purpose

A complex feature is the bridge component or member with advanced or unique structure members, operational characteristics, construction methods, and/or requiring specific inspection procedures. The focus is on the bridge component or member that warrants additional attention due to their inherent complexity. Bridges with complex features are identified in the SNBI Item B.IR.04 Complex Feature.



WisDOT has identified complex features as the mechanical and electrical elements of movable spans and the primary cables and anchorages of cable stayed bridges. Inspections results and procedures of bridges with complex features will be recorded and reported as follows:

Complex Feature	HSIS Inspection or Activity Type
Movable bridge mechanical and electrical elements	Movable Inspection
Cable stay – primary cables and anchorages	Complex Feature Inspection

Complex features are subject to specialized inspection procedures. Additional inspector training and experience is required to inspect structures with complex features. The inspection of complex features require greater engineering knowledge and/or expertise to accurately and fully determine the condition of the various bridge elements. They may also require specialized equipment or climbing to access these features. The qualification to inspect primary cables of a cable stayed bridge is to be a TL and possess the FC or NSTM NHI course certificate. Moveable bridge qualifications are described in Part 3 of this manual. The complex feature qualified inspection team leader must be present during the complex feature inspection.

1.3.13.2 Bridge Inspection Procedures

CFR 650.313(g) establishes the requirement for all complex structures to have a bridge specific inspection procedure in place. Complex feature inspection procedures are to address the following topics applicable to those features:

- Equipment needs
- Personnel needs and qualifications
- Access requirements
- Scheduling considerations
- Coordination with agencies and/or partners
- Risk factors
- Identify/describe the specific complex feature of the bridge to be inspected
- Explain the inspection methods and techniques to be utilized
- Description of the inspection interval
- Documentation requirements
- Reporting and follow-up processes

Movable structures should normally receive the same types of inspections as fixed structures, as described in the foregoing. Furthermore, most movable bridges will require additional



specialized inspections, such as NSTM, in-depth (movable), underwater diving, and underwater survey inspections. In addition to the structural systems, the operating systems need to be inspected on a routine basis. An annual in-depth inspection which WisDOT calls a Movable Inspection involves the inspection of the complex features of the mechanical and electrical systems of the movable bridge. It is typically most advantageous to perform the annual movable systems inspection in early spring. Specific inspection tasks relative to movable structures are described in detail in Part 3 of this Manual.

1.3.13.3 Complex Feature Inspection Interval

Complex Feature	Inspection Interval
Movable bridge mechanical and electrical elements	24-month Movable Inspection
Cable stay – primary cables and anchorages	96-month Complex Feature Inspection

The inspection TL will consult with the bridge specific PM to determine if the complex feature inspection interval must be decreased based on condition or other factors.

1.3.14 Closed Bridge - Routine Inspection

1.3.14.1 Purpose

Bridges closed to highway traffic that remain in the HSI system as highway bridges fall under two closure situations: (1) closed because of an active rehabilitation or repair project and (2) closed because the condition is unsafe for public use. The status in HSI system must be marked Closed.

Closed Due to Rehabilitation or Repair

Bridges closed because of an active rehabilitation or repair project have the following inspection related requirements.

1. A routine, NSTM, in-depth, and dive inspections (and all activities) are not required to be completed during a bridge closure for rehab.
2. FHWA does not require notification in advance of an inspection that will not be completed because of the bridge closure.
3. The bridge status in HSIS should be changed to CLOSED.
4. Grace dates should be considered and applied when necessary for all inspections due during the bridge closure period.
5. Safety of users on open facilities under a closed bridge and bridge closure system/traffic control for the closed bridge roadway approaches are the responsibility of the contractor and project management as part of the rehabilitation/construction contract.



6. The initial; and when necessary, missed routine, NSTM, in-depth, dive, inspections are **due within 3 months of the bridge opening to traffic**.
 - a. The initial inspection only requires the inspection of the elements and condition ratings for what was rehabbed.
 - b. A Routine, NSTM, In-depth, and Dive may be required if they were **not** completed because the bridge was closed – all should have been grace dated in HSIS.
7. If work is performed on NSTM or Dive elements during the rehab, the NSTM and/or Dive inspection are due within 12 months of the bridge opening to traffic. As noted in 5a above, the initial is due within 3 months of opening, so for optimization, it is best to perform NSTM, In-depth, Routine, and Initial at the same time.
8. When bridge is reopened to traffic, bridge status in HSIS should be changed to BUILT.

Closed Due to Safety Reasons

Bridges closed for safety reasons must continue to receive Routine inspections entered into HSIS. . Routine inspections will include, at a minimum, the following:

1. Evaluate the traffic control, signage, and closure system(s) recorded under Assessment 9036 Bridge Closure System
2. Evaluate primary structural elements for structural stability.
3. Evaluate safety for users accessing facilities/features on and under the bridge.
4. Notify the bridge owner of any safety concerns that required attention.

Inspections such as NSTM, Complex, Underwater, etc. are no longer required for the closed structure unless those inspections are crucial to ascertaining the stability of the structure in the field. The Regional PM shall be consulted to determine if these inspection types are required for individual bridges.

1.3.14.2 Interval

A routine inspection on closed bridge shall be conducted on a 12-month interval and shall be entered in the HSI system.

1.3.15 Closed Bridge Criteria

1.3.15.1 Introduction

A structural condition or deficiency that poses a threat to public safety requires an immediate full or partial closure of the bridge. A full or partial closure of the bridge is part of the critical finding procedure. Notifications and actions related to the critical finding procedure are described in more detail in Section 1.7. This section establishes the criteria based on bridge inspection findings and the primary reasons for prompt actions to close a bridge. This section also identifies actions to take should a closure be required. An inspection team leader, inspection program manager, or bridge owner should be involved in the decision to close a bridge. If an immediate threat to safety has been identified, the bridge closure or restriction



must be completed by any safe means necessary. By adhering to these criteria and conducting regular safety inspections, bridge inspectors and owners can make informed decisions regarding the closure of a bridge to prioritize public safety and infrastructure integrity.

1.3.15.2 Closure Criteria

The following criteria may prompt the full or partial closure of a bridge:

1. Structural Integrity –

- Structural damage or deterioration that compromises the safety of the bridge or the public.
- Safety inspections that reveal significant deficiencies or safety concerns, may prompt temporary closure until evaluated or necessary repairs are completed.
- Unarrested active crack in NSTM which has potential to cause member failure.
- SNBI Component Condition Rating (Item B.C.01-07, 11-15) ≤ 1 .
- Results of a Structural Review recommending closure.

2. Load Capacity (see Bridge Manual Section 45.10):

- Bridges not capable of carrying a minimum gross live load weight of three (3) tons at the Operating level must be closed.
- When deciding whether to close or post a bridge, the owner should consider the character of traffic, the volume of traffic, the likelihood of overweight vehicles, and the enforceability of a weight posting.

3. Flood Conditions – Closure may be necessary and justified during flood events to ensure the safety of the public. Bridges should be evaluated for safety before reopening to traffic after being closed due to flooding.

- Flood waters over bridge deck or roadway approaches.
- Flood waters into the superstructure pose a significant risk to bridge stability. Closure may be necessary during flood events to ensure safety. Bridges classified as scour critical have closure triggers identified in a bridge specific Scour Plan of Action.
- SNBI Component Condition Rating Item B.C.09 Channel Condition Rating ≤ 2 .

4. Emergency Situations:

- In the event of emergencies such as accidents, fires, terrorist threats, or natural disasters, closing the bridge may be necessary to ensure public safety or facilitate emergency response efforts.

1.3.15.3 Bridge Closure Actions

All factors requiring bridge closure cannot be anticipated; therefore, the actions listed below are general in nature and may not be applicable to all bridges. The following actions should be implemented when necessary.

1. Call 911 for assistance and notification (when needed). Contact local law enforcement as necessary to assist in setting up closure and detour.
2. Close the roadway over and under the structural elements in question. This can be achieved with vehicles, traffic control devices, and other methods for initial closure. More permanent closure systems and traffic control must be installed in a fastidious,

and expedited manner, and in accordance with the MUTCD, supplemented with the WisDOT MUTCD.

3. Contact appropriate owner agency to provide and establish traffic control. Follow the Critical Finding Notification process in Section 1.7.3.2.

4. Bridges over navigable waters -restrict or close the waterway by methods necessary. Notify the US Coast Guard.

5. Bridges over a railroad(s) – contact railroad owner.

6. For state owned bridges, contact the Traffic Management Center (414-227-2166), the region incident management coordinator (RIMC), and region operations/traffic section to coordinate appropriate traffic control and detour.

7. Restrict pedestrian access to the structural elements in question.

Notifications to relevant authorities should be provided with the necessary details of the closure, including the reason for the closure, initial steps taken, and the anticipated duration.

8. Plan for long term actions.

1.3.16 Load Posted Verification Activity

1.3.16.1 Purpose

A Load Posted Verification Activity is a review of the signage associated with a load posted bridge. Bridges not able to carry the State legal loads, as determined by the Statewide Program Manager (SPM), are load posted for reduced live load capacity. These bridges may have been designed for a truck load that is lighter than what is allowed by law today. Otherwise, these bridges may have suffered some sort of deterioration or damage that has reduced the load capacity below the legal statutory allowable load. In either regard, load posted bridges should be monitored regularly to ensure their serviceability and safety.



Figure 1.3.16.1-2: Load Posted Truss Bridge.



1.3.16.2 Precision

The inspector shall review the signage for the load posted bridge on-site to determine:

- Are all of the required load-posting signs (including advanced warning signs) in the proper locations?
- Are the signs legible, and do they have the correct load posting displayed?
- Does the HSI system have the correct load posting recorded in the data?
- Is Assessment 9034 (Weight Limit Posting) included in the inspection data?

The results of the inspection should be recorded as a Load Posted Verification activity in HSI (an inspection type is not required to be selected), including photos of ALL of the Signs. A new form [DT2122](#) is required when a form is not on file or the load posting has changed. This type of activity does not need to be performed by certified bridge inspectors. A Team Member can be sent out to perform specific inspection or measurement tasks under the direction of an Inspection TL.

The load posting can be found in the HSI system under the Capacity tab and is also included on page 2 of the inspection report under the Capacity Section. Inspectors should review the capacity information with in-service signs and do the following:

1. If the Load Posting (Capacity Section) is blank and no signs are present in the field, Assessment 9034 should not be used in the inspection, and should be removed if it has carried forward from a previous inspection where signs were present.
2. If the Load Posting (Capacity Section) does not match posting signs present in the field, assessment 9034 shall remain in the inspection report, activity “Load Posted Verification” shall be added on the Create/Edit tab in HSI, and the Load Posting Verification Form (DT2122) shall be submitted with the inspection.
3. If the Load Posting (Capacity Section) has a weight limit value but no signs are present, assessment 9034 shall be used with the appropriate missing sign quantities in CS4.

Load posting signs and installation shall comply with Section 2B.59 of the FHWA Manual on Uniform Traffic Control Devices (MUTCD) and the Wisconsin MUTCD. Bridges requiring load posting may also require advance posting signs at the nearest intersecting roads or other points where a driver can detour or turn around.

A bridge located close enough to an intersecting road that the load posting sign can clearly be read from that intersection should have the advanced sign placed at a further approach intersection. Additional advanced warning signs can be placed at other approach road intersections that may generate prohibited vehicles.

1.3.16.3 Interval

This activity only needs to be performed when load postings change on the structure. Load posting signs must follow the Wisconsin Manual on Uniform Traffic Control Devices and shall



be installed as soon as possible but no later than 30-days after the owner is notified of the need for the posting change. Missing or illegible posting signs shall be corrected as soon as possible but not later than 30 days after inspection or other notification determines a need. For structures that have a load posting at any level, form DT2122 – Bridge Load Posting Field Verification must be on record in HSI and must display the current signage. A new form is required when a form is not on file or the load posting has changed. This form shall be submitted immediately after sign installation.

1.3.17 Deck Evaluation Activity

1.3.17.1 Purpose

Over time, bridge decks deteriorate. Routine inspectors use various methods of inspection (both visual and audible) to detect defects in bridges decks.

Chain dragging is a common audible method to help detect delaminations and shall be recorded in HSI under the Deck Evaluation activity. Only when one hundred percent of the wearing surface is chain dragged shall the Deck Evaluation activity be selected in HSI.

A sketch of the delaminated areas shall be uploaded into HSI for the activity. Often times, more in-depth methods are required to ascertain condition. Common methods employed by WisDOT include:

- Ground Penetrating Radar (Part 5, Chapter 10)
- Infrared Thermography (Part 5, Chapter 11)
- Chloride Ion testing (Part 5, Chapter 16)

When these testing methods are used, they shall be recorded in HSI under the Deck Evaluation activity and all reports from the testing shall be uploaded into the activity.

The deck evaluation activity is performed by a team member under the direction and oversight of an inspection team leader at intervals based on information provided in SIM Part 1 Appendix A.

1.3.17.2 Precision

Refer to Part 5 of this manual for anticipated precision of each method.

1.3.17.3 Interval

For state-owned structures, deck evaluation interval is based on the Deck Scanning Policy in Part 1 Appendix A. Local bridge owners may choose to follow a similar interval to aid in the selection of appropriate bridge treatments.

**1.3.18 Scour Plan of Action Activity****1.3.18.1 Purpose**

The National Bridge Inspection Standards (NBIS) regulation, CFR 650.313(o), requires *bridges determined to be scour critical or have unknown foundations, prepare and document a scour plan of action (POA) for deployment of scour countermeasures for known and potential deficiencies, and to address safety concerns. The plan must address a schedule for repairing or installing physical and/or hydraulic scour countermeasures, and/or the use of monitoring as a scour countermeasure. Scour plans of actions should be consistent with HEC 18 and 23.*

In HSIS, a POA activity needs to be selected and the scour POA document uploaded under the documents/images tab.

1.3.18.2 Precision

In general, a plan of action should focus on providing information that the inspector needs when out in the field. The plan should refer to plans, previous inspector reports, UW-Profile data, and other items pertinent to the bridge.

The POA should detail the foundation type, previous scour history, and monitoring benchmarks for the inspector to assess while in the field. It should also include a bridge closure plan that details when the bridge should be closed, who's responsible for the closure, when the bridge can be re-opened and what detour route should be used during the closure.

1.3.18.3 Interval

The POA document shall be updated every four calendar years or after significant flooding events. This requires a new POA activity entry into HSIS.

A POA is required for bridges with a scour vulnerability (B.AP.03) code of C, D, E, U or 0.

Bridges with a Scour Plan of Action (item B.AP.04) = N or Y (required scour POA) or scour vulnerability (Item B.AP.03) = C, D, E, U or 0 must have a post-flood activity of cross sections (profile) and probing after a significant flooding event or at times as described in an implemented POA. Document and record the cross sections (profile) and probing in HSIS.

1.3.19 Vertical Clearance Measured Activity**1.3.19.1 Purpose**

The clearances on or under a bridge shall be measured periodically to determine changes in clearance that affect the mobility of Oversize/Overweight vehicle traffic.



Figure 1.3.19.1-1: Vertical Clearance Photo

1.3.19.2 Precision

Clearances should be taken in every lane, at edge of lanes, edge of paved shoulders, and at barrier edges to determine the low point for vehicular travel. Create the vertical clearance activity in HSI and upload the document(s) under the documents/images tab showing an elevation view photo which includes the locations and dimensions of the vertical clearances.

1.3.19.3 Interval

This activity shall be completed every time there is a construction project on or under a bridge. In addition, after a bridge is hit the inspector conducting the damage inspection should determine if they need to re-measure clearances and if so, enter a vertical clearance verification along with the damage report.

1.3.20 Critical Findings Activity

1.3.20.1 Purpose

A critical finding (CF) is a structural or safety related deficiency that requires immediate action to ensure public safety. Furthermore, a CF is a deficiency found on a bridge which critically threatens the structural stability of the bridge and/or the public safety, and is of such severity that requires immediate follow-up action. See Part 1, Chapter 7 for more details.



Figure 1.3.20.1-1: Critical Finding Photo

1.3.20.2 Precision

When criterion is met to designate a critical finding, as defined by Part 1, Chapter 7, a critical findings activity shall be entered into HSIS with a completed DT2026 form attached.

1.3.20.3 Interval

This activity is entered into the HSI System on an as-needed basis.

1.3.21 Structural Review Activity

1.3.21.1 Purpose

A structural review is completed by a licensed Wisconsin Professional Engineer to evaluate the observed field conditions and determine the impacts on the load rating and safety of the structure. Structural reviews may include a review of the field inspection notes and photographs, review of as-built plans or analysis as deemed appropriate by the engineer.

Both the owner and designated program manager of the bridge are responsible for ensuring that a qualified individual completes and documents the review in the Highway Structures Information System (HSIS). For locally owned structures, the local bridge owner is required to have a staff engineer, or consultant engineer perform the review (PE required).



1.3.21.2 Precision

Triggering events:

- When a primary structural element is newly observed to be in a severe condition (CS4).
- When the quantity of a pre-existing CS4 primary structural element has increased since the last inspection.
- When the quantity of a pre-existing CS4 primary structural element has not increased, but the severity of the defect has worsened (i.e. section loss from physical measurements increased from 15% to 25% since last review).

Timeline:

- The structural review shall be completed no later than 60-days after the inspection.
- The review must be documented in HSIS; the inspection that documented the defect cannot be signed without the review documentation entered.
- If during the review the defect is determined to be a Critical Finding, the owner agency shall follow the timeline(s) and steps set forth by that policy found in Part 1 Chapter 7.
- Repairs can be performed in lieu of the Structural Review, provided the repair is either a standard repair detail from WisDOT or the repair has been designed by a Wisconsin PE.
- The repair must be completed within 60 days of the finding. The inspection cannot be closed out until the repair is completed, and the plans and calculations are uploaded into the HSI system, along with photographs of the completed repair.

Requirements:

- If the result of the structural review indicates the need for a long-term bridge or lane closure, this shall happen immediately, and the Critical Findings policy and procedures shall be followed. Contact the Statewide Inspection Program Manager.
- If the result of the structural review indicates that the bridge be load posted, or the existing load postings be lowered, the agency shall follow load posting requirements set forth by the Department.
- If the review indicates that the load capacity of the structure is not controlled by the defect, then no action is required.
- In all cases (except error) the defect quantity shall remain in CS4 regardless of the outcome of the structural review until the element is repaired or replaced.

Documentation:

For all triggering events, the results of the review shall be documented in HSIS as follows:

- Under the Inspection tab, when a trigger event is entered as part of an inspection into HSIS for the element and defect, a Structural Review tab will appear. On that tab, the Engineer will enter the following information:
 1. Reviewer name and PE number.
 2. Method of review (engineering judgement, analysis, etc.)
 3. Overall notes pertaining to the review, as well as specific notes for each primary structural element that has a CS4 quantity.
 4. Final recommended actions (load postings, closures, repair, monitoring, etc.)
- If calculations were performed, they must be uploaded into the HSI system.



A structural review is **required** for the following element/defect combinations (and will be automatically selected by the HSIS):

- Any steel superstructure, substructure, or culvert element(s) with these Severe (CS4) material defects:
 - (1000) Corrosion
 - (1010) Cracking
 - (1020) Connection
 - (1900) Distortion
- Any concrete (prestressed or reinforced) superstructure or substructure element(s) with these Severe (CS4) material defects:
 - (1080) Delaminations/Spalls/Patch Areas/Exposed Prestressing
 - (1110) Cracking PSC
 - (1130) Cracking RC
 - (1190) Abrasion/Wear
 - (8906) Precast Concrete Connections
- Any timber superstructure or substructure element(s) with these Severe (CS4) material defects:
 - (1020) Connection
 - (1140) Decay/Section Loss/Abrasion/Wear
 - (1150) Checks/Shakes/Cracks/Splits/Delamination
 - (1900) Distortion
- Any masonry superstructure or substructure element(s) with these Severe (CS4) material defects:
 - (1610) Mortar Breakdown
 - (1620) Splits/Spalls/Patched Areas
 - (1640) Masonry Displacement
- Any substructure element with these Severe (CS4) structural defects:
 - (4000) Settlement
 - (6000) Scour
- Any bearing element with this Severe (CS4) material defect:
 - (2240) Loss of Bearing

In all other situations, the inspector may request a structural review for an element/defect combination if he/she feels that the condition warrants a review by a professional engineer.

The following is the structural review process guide to assist inspectors in HSI entry:

